Philips
Steamer

9 L 900 W

optimal preset timings

HD9140

# Discover fuller flavours

## Add your own taste with the flavour booster

This high-quality steamer with unique Flavour Booster improves steamed food with the delicious aroma of herbs and spices. Preset timings, a Keep Warm function and an expert recipe booklet all help you prepare delicious meals every time.

### Discover fuller flavours

- Flavour Booster improves taste with delicious herbs and spices
- Optimal preset timings for fish, vegetables, rice and more
- Recipe booklet packed with expert tips and tasty treats

### Smart features

- Removable 500 ml drip tray is easy to pour from and clean
- Cord storage keeps kitchen surfaces neat and tidy
- Stackable steaming tiers use less space for storing
- Descale indicator light with bell, signals when to descale
- Water refill indicator signals when water level is low

### Only a little effort

- Dishwasher-safe parts make cleaning easy
- External water inlet for refilling reservoir during use
- Digital timer with ready signal and auto shutoff
- Keep Warm function keeps food ready for serving

PHILIPS

sense and simplicity

Steamer
9 L 900 W optimal preset timings

HD9140/30

# Highlights

## Flavour Booster

The unique Flavour Booster improves food with the delicious aroma of herbs and spices, bringing true taste to steaming. Simply pop your favourite herbs and spices into the booster, and let steam do the rest. The heat from the steam releases delicate aromas from the herbs and spices, which thoroughly infuse the food with their mouth-watering flavours.

## Optimal preset timings

Steaming is a delicate art, which is why the Philips Steamer has a wide range of preset timings that automatically shut off the steam once the ideal steaming time is reached. That will help you to cook a huge variety of foods—including rice, eggs, vegetables, chicken and fish—achieving perfect results that retain all the flavour and vitamins.

## Recipe booklet

Recipe booklet packed with expert tips and tasty treats.

## Descale indicator

Descale indicator light with bell, signals when to descale.

## Dishwasher-safe parts

Dishwasher-safe parts make cleaning easy.

## Cord storage

Cord storage keeps kitchen surface neat and tidy.

## Stackable steaming tiers

Stackable steaming tiers use less space for storing.

## External water inlet



External water inlet for refilling reservoir during use.

## Water refill indicator

Water refill indicator signals when water level is low.

# Specifications

## Design specifications

- Material: Plastic with stainless steel parts
- Colour(s): White/metal/red

## Accessories included

- Egg rack
- Rice/soup/food container: 1.2 l

## General specifications

- Non-slip feet
- Power-on light
- Cool-touch handgrips
- Water level indicator
- Overheat and dry boil protection
- Number of tiers: 3 pcs

## Weight and dimensions

- Weight of the appliance: 2.3 kg
- Product dimensions (W x H x D): 312 x 450 x 227 mm

## Technical specifications

- Power: 900 W
- Voltage: 220-240 V
- Frequency: 50/60 Hz
- Cord length: 100 cm
- Capacity tiers: 2.5/2.6/3.5 l
- Capacity water tank: 1.1 l

Issue date 2010-01-18

Version: 1.0.1

12 NC: 0000 000 00000

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com